Right-side keypad

EOS R5 / R5 Mark II / R6
R6 Mark III / R7

1. **Autofocus** (exposure metering) and shooting mode change.
To change the shooting mode, hold down key 1 until the red LED lights up (15 sec.).

2. **Shutter release**:
Mode 1: Pressing the key activates autofocus; releasing it takes the photo (Default Setting).
Mode 2: Pressing the key activates autofocus first, then releases the shutter. (If the objective is already in focus, the photo is taken immediately.)
In video mode, the key becomes REC.

3. **Mode Change.**
Set the Camera to Mode M.
R5 (M/Av/Tv/P).
R5 Mark II (M/Av/Tv/P/B/Fv/Auto/C1/C2/C3).
For R7, Shutter/Rec key.
On R6 and R6 Mark III, enables or disables sensor Crop in video mode.

Keys 4,5,6,7 change function according to the Mode set on the Camera.

Manual Mode:	**M. Shutter Priority (TV)**	**M. Aperture Priority (AV)**	**Mode P:**
4. Aperture −	***4.*** EV −	***4.*** Aperture −	***4.*** EV −
5. Aperture +	***5.*** EV +	***5.*** Aperture +	***5.*** EV +
6. Shutter speed −	***6.*** Shutter speed −	***6.*** EV −	***6.*** EV −
7. Shutter speed +	***7.*** Shutter speed +	***7.*** EV +	***7.*** EV +

Press adjustment Keys 4,5,6,7,8,9 once to change by one step.
Hold down to change the selected setting quickly.

8. **ISO +**

9. **ISO −**

10. **On/Off**.
Press once to turn on; to turn off, hold for about two seconds until the board switches off. The camera will Auto Power Off after the time set in its menu. To turn the camera on again, press this key, wait for the board to power up, then press key 2.



Leo3 keypad - Right

Front Rear

.

Easydive®

Canon

Left-side keypad

leo³

EOS R5 / R5 Mark II / R6
R6 Mark III / R7

1. **Focus point movement**, 9 positions around the perimeter plus a central position.

2. **Zoom of the focus point.**

R5/R6/R6mkIII/R7: x5 and x10
R5 Mark II: x6 and x15.

3. **Focus area mode**.

4. **Video mode activation**. Press key 4 again to return to photo mode.

5. **Change white balance (WB) preset.**

6. **Autofocus Mode.**
In photo mode, selects ONE SHOT - SERVO.
R5/R6: MF also available.
R5 Mark II/R6 Mark III: AI FOCUS also available.
In Video mode, enables or disables the SERVO option.

7. In photo mode: **Drive mode.**
In video mode, selecting the **Custom WB** position with key 5 allows manual white balance capture.
Holding key 1 on the right-side keypad also enables sensor Crop.

8. In photo mode: **Metering Mode**.
In video mode: **Change video resolution**, moves up one step.

9. In photo mode: **Photo quality**.
In video mode: **Change video resolution**, moves down one step.

10. **Board On/Off** internal electronics.
Press once to turn on; to turn off, hold for about two seconds until the board switches off. The camera will Auto Power Off after the time set in its menu. To turn the camera on again, press this key, wait for the board to power up, then press key 2 on the right-side keypad.



Leo3 keypad - Left

Rear Front

Video mode must be selected manually before placing the camera in the housing.